Consumption Seal Oil Leak From Compressor Black Exhaust Smoke **Engine Oil** Turbocharger Troubleshooting **Engine Lacks Power** Excessive Cause Remedy Replace element according to engine manufacturers recommendations Clogged air filter element Obstructed air intake duct to turbo compressor Remove obstruction or replace damaged parts as required Obstructed air outlet duct from compressor to intake manifold Remove obstruction or replace damaged parts as required Obstructed intake manifold Refer to engine manufacturers manual & remove obstruction Air leak in duct from air cleaner to compressor Correct leak by replacing seals or tightening fasteners as required Air leak in duct from compressor to intake manifold Correct leak by replacing seals or tightening fasteners as required Air leak at intake manifold to engine joint Refer to engine manufacturers manual & replace gaskets or tighten fasteners as required Obstruction in exhaust manifold Refer to engine manufacturers manual & remove obstruction Obstruction in muffler or exhaust stack Remove obstruction or replace faulty components as required Gas leak in exhaust manifold to engine joint Refer to engine manufacturers manual & replace gaskets or tighten fasteners as required Gas leak in turbine inlet to exhaust manifold joint Replace gasket or tighten fasteners as required Gas leak in ducting after the turbine oultet Refer to engine manufacturers manual & repair leak Obstructed turbocharger oil drain line Remove obstruction or replace line as required Obstructed engine crackcase vent Refer to engine manufacturers manual, clear obstruction Turbocharger center housing sludged or coked Change engine oil & oil filter, overhaul or replace turbo as required Fuel injection pump or fuel injectors incorrectly adjusted Refer to engine manufacturers manual - replace or adjust faulty components(s) as required Engine camshaft timing incorrect Refer to engine manufacturers manual & replace worn parts Worn engine piston rings or liners (blowby) Refer to engine manufacturers manual & repair engine as required Internal engine problem (valves, pistons) Refer to engine manufacturers manual & repair engine as required Dirt caked on compressor wheel and/or diffuser vanes Clean using a Non-Caustic cleaner & Soft Brush. Find & correct source of unfiltered air & change engine oil & oil filter Damaged turbocharger Analyze failed turbocharger, find & correct cause of failure, overhaul or replace

turbocharger as required